




Ref. nr. Ref. No.	Benämning	Description	Detalj nr. Part No.	Antal / skiss Qty / Sketch
1	Vred M16	Knob M16	AXCS-0501	1
2	Bygel	Clamp / support	AXCE-0502	1
3	Stöd hjul	Support - wheel	AXCS-0503	1
4	Mutter M16	Nut M16	AXCS-0504	1
5	Låshandtag M10x20	Lock handle M10x20	AXCS-0505	2
6	Teleskåp - överdel	Telescope - upper part	AXCE-0506	1
7	Teleskåp - underdel	Telescope - lower part	AXCE-0507	1
8	Instruktionshållare	Instruction holder	AXCE-0101	1
9				
10				
11				
12				
13				
14				
15				



Ref. nr. Ref. No.	Benämning	Description	Detalj nr. Part No.	Antal / skiss Qty / Sketch
1	Vänsterskänkel	Left-hand shank	AXCE-0102	1
2	Högerskänkel	Right-hand shank	AXCE-0103	1
3	Skruv M16x130	Screw M16x130	AXCS-0302	1
4	Skruv M16x100	Screw M16x100	AXCS-0301	2
5	Skruv M16x140	Screw M16x140	AXCS-0303	1
6	Bricka 17x30x3	Washer 17x30x3	AXCS-0304	4
7	Bärhjul	Carriage wheel	AXCS-0306	4
8	Låsmutter M16	Locking nut M16	AXCS-0305	4
9	Saxsprint 4x35	Cotter pin 4x35	AXCS-0204	2
10	Vaggaxel	Cradle axle	AXCE-0203	2
11	Vagga	Cradle	AXCE-0202	2
12	Bärrulle	Carriage roller	AXCS-0201	8
13	Handtag	Handle	AXCS-0401	1
14	Pumpspak	Pump lever	AXCE-0402	1
15	Fjäder	Spring	AXCS-0403	1
16	Låsmutter M8	Locking nut M8	AXCS-0404	1
17	Glidlager	Slide bearings	AXCE-0405	1
18	Skruv M8x55	Screw M8x55	AXCS-0406	1
19	Skruv M14x140	Screw M14x140	AXCS-0407	1
20	Pumpspakshållare	Pump lever holder	AXCE-0408	1
21	Sänkpedal	Lowering pedal	AXCE-0409	1
22	Låsmutter M14	Locking nut M14	AXCS-0410	1
23	Skruv M8x10	Screw M8x10	AXCS-0411	1
24	Bricka 8x19x2	Washer 8x19x2	AXCS-0412	1
25	Säkringsspärr	Safety lock	AXCE-0413	1
26	Mutter M14	Nut M14	AXCS-0104	1
27	Bricka 14X35X2	Washer 14X35X2	AXCS-0105	1
28	Skruv M14x30	Screw M14x30	AXCS-0106	1
29	Låsbar låsspärr	Lockable locking device	AXCS-0107	1
30	Låsspärr	Locking device	AXCS-0108	1
31	Täckplugg 90x50	Cover plug 90x50	AXCS-0109	2
32				
33				
34				
35				
36				
37				
38				
39				
40				

B4





Ref. nr. Ref. No.	Benämning	Description	Detalj nr. Part No.	Antal / skiss Qty / Sketch
1	Förlängare	Extension rod	AXHC-0303	1
2	Cylindergavel	Cylinder end	AXHC-0201	1
3	Kolvstång	Piston rod	AXHC-0302	1
4	Lyftkolv	Lifting piston	AXHC-0301	1
5	Skruv M12*25 12.9	Screw M12*25 12.9	AXHS-0101	1
6	Cylinderrör	Cylinder pipe	AXHC-0304	1
7	Kanalar	Channel pipe	AXHC-0401	1
8	Tankrör	Tank pipe	AXHC-0402	1
9	Plugg M10*1	Plug M10*1	AXHS-0102	1
10	Cylinderanslutning	Cylinder connector	AXHC-0101	1
11	Pumphus	Pump house	AXHP-0100	1
12	Plugg	Plug	AXHV-0600	1
13	Backventil	Check valve	AXHV-0500	1
14	Backventil	Check valve	AXHV-0400	1
15	Pilotstyrd backventil	Pilot valve	AXHV-0300	1
16	Skruv M8*100 12.9	Screw M8*100 12.9	AXHS-0103	1
17	Högtryckpump	High pressure pump	AXHP-0301	1
18	Snabbtransportpump	Quick transport pump	AXHP-0201	1
19	Styrring	Guide ring	AXHP-0202	1
20	Säkringsring	Safety ring	AXHS-0105	1
21	Trycksäkringsventil	Safety pressure valve	AXHV-0100	1
22	Riktningventil	Alignment valve	AXHV-0200	1
23	Skruv M8*80 12.9	Screw M8*80 12.9	AXHS-0104	1

Ref. nr. Ref. No.	Benämning	Description	Detalj nr. Part No.
	Packningssats hydraulpump	Repair kit hydraulic pump	AXHS-9101
	Packningssats hydraulcylinder	Repair kit hydraulic cylinder	AXHS-9102
24	Hydraulpump	Hydraulic pump	AXHE-9201
25	Hydraulcylinder	Hydraulic cylinder	AXHE-9202
26	Hydraulenhet	Hydraulic unit	AXHE-9203